



INSTALLATION STEPS

ATTENTION: Risk of fire and electrical shock - fixture to be installed by qualified contractor according to local codes and ordinances

- 1** [A] - Canopy connections: White+, Black-, Green, (if dimming is required): Purple Dim+, Gray Dim-
- [B] - Attach bracket bar with 1/4-20 stud and cover with canopy, securing with aircraft gripper.
- [C] - Attach second aircraft gripper to ceiling or tbar grid, adjust aircraft cable height, and secure grippers by twisting safety nut clockwise.

NOMINAL SUSPENSION POINT DISTANCES

NOMINAL FIXTURE LENGTH	4FT	8FT	8FT (X)
SUSPENSION POINT LENGTH	45.00"	90.20"	90.00"

FOR ROWS:

When rows are ordered, row sections will be labeled in sequence. Position section in proper order prior to installation (ie place 1 to 1).

- 1** Complete steps 1
[D] - Remove top & bottom lenses. Apply suction cup (provided) to one end and carefully pull lens out
- 2** [A] - Join quick connectors
[B] - Align top joiners.
[C] - Secure sections with the joiner screw.
- 3** [A] - Align bottom joiners.
[B] - Secure sections with the joiner screw.
- 4** [A] - Verify if fixture is leveled.
[B] - If needed, adjust aircraft cable height, and secure grippers by twisting safety nut clockwise.
[C] - Repeat step [B] and validate that the fixture is leveled.
Repeat steps for all grippers in row
- 5** [A] - Excess aircraft cable should be tucked inside the body. Reinstall lenses on the main body.
Repeat step for all length of row